


Datasheet – TEC Controller TEC-1091 (±4 A / ±21 V)



Support / First steps

Meerstetter Engineering provides technical support for all products and helps you to integrate a product into your solution. Most of your questions should be solved by reading the provided <u>user manuals</u> of the corresponding product or the <u>FAQ</u> (frequently asked questions).

For further help or if you have any other questions please do not hesitate to contact us. We are happy to help you. You can contact us by email support@meerstetter.ch.


Meerstetter's product family compatibility

The Meerstetter LDD and TEC-Family have been developed to work along with each other. They share the same platform bus, communication protocol and hardware architecture. See Table for an Overview over the LDD- and TEC-Families.

LDD-Family		
LDD-1321	0-1.5 A / 0-14 V	CW, Add on TEC Controller available
LDD-1301	0-20 A / 0.5-45 V	1 ms - CW
LDD-1303	0-20 A / 1-120 V	1 ms - CW
LDD-1137	0-75 A / 0-70 V	0.5 µs - CW, modulated, QCW and pulsed modes
LDD-1124-SV	0-1.5 A / 0-15 V	1 μs - CW, modulated, QCW and pulsed modes
LDD-1121-SV	0-15 A / 0-15 V	1 μs - CW, modulated, QCW and pulsed modes
LDD-1125-HV	0-30 A / 0-27 V	1 μs - CW, modulated, QCW and pulsed modes
TEC-Family		
TEC-1092	±1.2 A / ±9.6 V	Micro, single channel
TEC-1091	±4 A / ±21 V	Small, single channel
TEC-1089-SV	±10 A / ±21 V	Medium, single channel
TEC-1162	±5 A / ±56 V	Medium-high, single channel
TEC-1090-HV	±16 A / ±30 V	Large, single channel
TEC-1163	±25 A / ±56 V	Extra-large, single channel
TEC-1161-4A	2 x (±4 A / ±21 V)	Small, dual channel
TEC-1161-10A	2 x (±10 A / ±21 V)	Medium, dual channel
TEC-1122-SV	2 x (±10 A / ±21 V)	Medium, dual channel
TEC-1166	2 x (±5 A / ±56 V)	Medium-high, dual channel
TEC-1123-HV	2 x (±16 A / ±30 V)	Large, dual channel
TEC-1167	2 x (±25 A / ±56 V)	Extra-large, dual channel

HW v3.40 and HW v3.50

Small OEM TEC Controller



The TEC-1091 is a specialized TEC Controller / power supply able to precision-drive a single Peltier element.

It features a true bipolar DC current source for cooling / heating, two temperature monitoring inputs (1x main, 1x auxiliary) and intelligent PID control with auto tuning. The TEC-1091 is fully digitally controlled, it's hard- and firmware offer numerous communication and safety options.

The included PC-Software allows configuration, control, monitoring and live diagnosis of the TEC Controller via USB, RS485 and RS232 TTL. All parameters are saved to non-volatile memory. Saving can be disabled for bus operation.

For the most straightforward applications, only a power supply, Peltier elements and two temperature sensors need to be connected to the TEC-1091. After power-up the unit will operate according to pre-configured values. (In stand-alone mode no control interface is needed.)

The TEC-1091 can handle either Pt100, Pt1000, NTC or Voltage temperature probes. For highest precision and stability applications a Pt100 / 4-wire input configuration is recommended. Analog measurement circuit is factory calibrated.

Auxiliary temperature input allows the connection of an NTC probe that is located on the heat sink of the Peltier element. This additional data is used to compensate for parasitic thermal conduction of Peltier element. Also, it allows the control of an external heat sink cooling fan.

The heating and cooling power is optimized by proprietary thermal management routines based on power balance models (for Peltier elements and resistive heaters).

Further functionality includes: Smooth temperature ramping, thermal stability indication and auto gain (NTC probes). The PC-Software allows data logging and configuration import/export.

Many features (hardware, software) of this OEM product are customizable upon request.

Features

Output Stage:

- DC Input Voltage: 5 24 V
- Output Voltage: 0 to ±21 V (max. ~ 0.9 · U_{IN})
- Output Current: 0 to ±4 A, <1 % Ripple (TEC Modules with higher Output Power available)

Main Features:

- Temperature Sensor Types: Pt100, Pt1000, NTC, Voltage
- Temperature Precision / Stability: <0.01 °C
- Temperature Control & Measurement Frequency: 1 Hz, 10 Hz, 80 Hz
- Performance-optimized PID for Thermal Power Control
- Configuration / Diagn. over USB / RS485 PC Software
- Dimensions (L x W x H): 65 mm x 38 mm x 14 mm
- Efficiency: 96 % (@ 90 % Load)
- Cooling not required (natural convection)
- Auxiliary Peltier Heat Sink NTC Temp. Sensor Input

Operation Modes:

- Stand-Alone without Live Control Interface
- Remotely-Controlled over USB, RS485 / RS422, RS232 TTL, CANopen CiA 301, I/O
- Script-Controlled over Lookup Table Read-Out

Driver Modes:

- DC Power Supply: Set Current or Voltage
- Temperature Control: PID Settings, Auto Tuning, optional Cool/Heat-Only or Resistor modes

Data Interfaces:

- USB 2.0 1kV isolated (FTDI Chip)
- 1x RS485 / RS422
- 1x RS232 TTL
- CANopen CiA 301

General Purpose I/O Features:

- 4x Digital I/O Signals (3.3 V / 5 V)
- Configurable as Input to control TEC-1091 (Enable, Temperature Up / Down etc.)
- Configurable as Output to monitor TEC-1091 (Error Indication, Temperature Stable Indication etc.)

Optional Components:

• Various displays available up to 4x20 Chars (DPY-1113)

Further Information:

- Please contact us for additional information or consult the current TEC Controller User Manual (Document 5216).
- The TEC-1091 is part of the TEC-Family of Meerstetter TEC Controllers. It is designed to operate alongside devices of the LDD-Family of laser diode drivers. Both families of drivers share the same system bus, design, technology and physical dimensions.




Absolute Maximum Ratings


Supply voltage (DC) 27 V

Bipolar output voltage	±24 V
Bipolar output current	±6 A

Operating Characteristics for all firmware versions

Temperature -40 – 90 °C





Document Number: 5175S (30 October 2023)

Standard or Extended Device Temperature Mode can be set as software setting. Using forced air cooling, it is possible to enhance the ambient temperature performance.

Electrical Characteristics

Unless otherwise noted: T_A = 25 °C, U_{IN} = 24 V, R_{load} = 3.75 Ω , FW >= v4.00

Symbol	Parameter	Test Conditions	Min	Тур	Max	Units	
DC Power Supply Input:							
U_{IN}	Supply voltage		4.9		24	V	
U _{IN} Ripple	Ripple tolerance	UIN never below UIN min			300	mV_{PP}	
Output:							
Гоит	Bipolar current swing				±4	Α	
U _{OUT}	Bipolar voltage swing	U _{OUT} is maximum ~0.9 ⋅ U _{IN} ; See diagram			±21	V	
U _{OUT} Ripple	Voltage ripple	@ 4 A		80		mV_{PP}	
I _{OUT} Drift	Output current			0.1		mA/°C	
	temperature drift						
System Cha	racteristics:						
η50%	Power efficiency	@ 50 % load (10.5V, 4A)		94		%	
η100%	Power efficiency	@ 100 % load (21V, 4A)		96		%	
Output Monitoring (Iout Resolution is 1.46mA; Uout Resolution is 6.1mV)							
louт Read	Precision	@ 3.8 A		1	5	%	
Uout Read	Precision	@ 15.0 V		1	3	%	

Output Safety Characteristics

Unless otherwise noted: $T_A = 25$ °C, $U_{IN} = 24$ V

Symbol	Parameter	Test Conditions / Hints	Min	Тур	Max	Units		
Output Stag	Output Stage Protection Delays:							
toff	Short circuit	Full load condition		10	30	μS		
toff	Power system limits				200	μS		
Output Stage Current Supervision: (If the OUT+ and OUT- currents differ too much, an error is generated)								
IOUT_DIFF	Error threshold			400		mΑ		



Object Temperature Measuring Characteristics (Pt100 and Pt1000 Probes)

Measurement configuration = 23bit / 4-wire / unshielded cable <50mm

Symbol	Parameter	Test Conditions / Hints	Min	Тур	Max	Units
Tobj, range	Range	Range is extendable upon request Default measurement range is -220 °C +200 °C Extended measurement range is -193 °C +787 °C			+200	°C
T _{OBJ} , PREC	Precision	(EN 60751 / IEC 751)		0.005	0.01	°C
T _{OBJ} , COEFF	Temp. Coefficient	Relative to device temperature			1.6 m	°C/K
Tobj, noise	Value Noise	Reference measurement fluctuations while output stage operating @ 70 % load		0.003		°C
T _{OBJ, REP}	Repeatability	Repeated measurements of reference resistors after up to 3 days		0.005		ô

Object Temperature Measuring Characteristics (NTC Probes)

NTC thermistor resistive input characteristics translate into temperature ranges valid for only one type of NTC probe. Below example is given in the case of an NTC $B_{25/100}$ 3988K R_{25} 10k temperature sensor.

Symbol	Parameter	Test Conditions / Hints		Тур	Max	Units
Robj, range	ADC Auto Gain PGA = 1 or 8 or 32	Standard Configuration $R_s = 56 \text{ k}\Omega$			55742	Ω
		Corresponding temperature range		176 to -10.1		°C
		Very Low-°T Configuration NTC	73		1M	Ω
		Corresponding temperature range	194.3 to -55.5		.5	°C

ROBJ, RANGE is resistance range of the NTC sensor

Object Temperature Monitoring Configuration (Voltage Measurement VIN1 / VIN2)

Sensors with linear Voltage/Temperature output.

Symbol	Parameter	Test Conditions / Hints	Min	Тур	Max	Units
V _{SENS, DIFF}	Range	Differential Input voltage Temperature range depends on sensor used	-2.039		2.039	٧
V _{OBJUx} , ABS	Range	Absolute Input voltage	-0.1		5.1	V

Sink Temperature Measuring Characteristics (NTC only)

T_A = 25 °C, measurement configuration = 12bit / 2-wire / unshielded cable <50 mm, °T probe = NTC B_{25/100} 3988K R₂₅ 10k

Symbol	Parameter	Test Conditions / Hints	Min	Тур	Max	Units
Б	Danna		50		49781	Ω
KSINK, RANGE	Range	Corresponding temperature range		214 to -8.1		°C

RS232 TTL and General Purpose Digital I/O Characteristics (GPIO1 ... GPIO4, RX, TX)

Unless otherwise noted: $T_A = 25$ °C, $U_{IN} = 24$ V

Symbol	Parameter	Comments	Min	Тур	Max	Units				
Input Cha	Input Characteristics:									
U _{IH}	Logic high input threshold		2.38			V				
U _{IL}	Logic low input threshold				0.93	V				
U _{IMAX}	Maximum input voltage		-0.5		5.5	V				
Output Cl (Microproces	naracteristics:									
Uон	Logic high output voltage	Output current 8mA	2.8			V				
Uol	Logic low output voltage	Input current 8mA			0.4	V				
	ESD Protection: (Between Processor and Connector)									
U _{PP}	ESD discharge	IEC61000-4-2			100	kV				
RA	Series resistance		170	200	230	Ω				


Document Number: 5175S (30 October 2023)



Package Outline and Pin Configuration СЭ 679 C 8 8 __ _ C87 VIN R38 OUT+ UI U12 C75 **GND** OUT-11 GPIO1 GND (NC) 627 CIO GPIO₂ SINK T° B ∑∑ ∞ GPIO3 R43 SINK T° A [w] GPIO4 **SHIELD** [c99] U14 L 282 RS232 TTL RX OBJ T° UB **E E** RS232 TTL TX OBJ T° UA G1 E RS485 A2 (D+), CANH OBJ T° IB RS485 B2 (D-), CANL Ö₿J T° IA 33 [D4] [D3] [m] [m] (0,0)Mini USB D=0 0 0 RBI Dimensions (L x W x H): 65 mm x 38 mm x 14 mm Ů16 R2 R26 [cst] Z X1 and X2 can be equipped with different connector options. 3 ctot U8 Please contact Meerstetter engineering with your inquiry.

- For direct PCB mounting: If the TEC Controller is powered by a sensitive power supply net, it is recommended decouple the TEC Controller Supply by some filter components. Please contact us for further information.
- For direct PCB mounting: Do not place any component under the TEC Controller.
- RP, RS and the two Jumpers R2 and R3 define the Object Sensor Type
- R81 is for VIN2, which connects IA directly to the 5 V supply.

R1 is the optional 120 Ω termination for RS485



Peltier element, temperature probes, power supply and connectors not included.




Operation-Modes and Communication Options

The TEC-1091 is an OEM precision TEC Controller that is primarily designed to operate as a stand-alone device. Once configured and in operation, its basic status is visually indicated by on-board green and red LEDs and their blinking pattern. More detailed status information can be polled at any time by industry-standard RS485 / RS232 TTL connection or by USB (see box below). The TEC-1091 can also operate in a remotely-controlled manner, with parameters adjusted on the fly.

Configured as a DC power-supply, the TEC-1091 can handle current and voltage settings. In the remote-control case, temperature data may be passed on to be processed by the host.

Configurable parameters further include: sensor linearization (Pt100 / Pt1000) and Steinhart-Hart modeling (NTC), temperature acquisition hardware calibration, Peltier element modeling, PID controller auto tuning, nominal temperature ramping, current, voltage and temperature limits, error thresholds, etc. Please refer to the TEC Controller User Manual (Document 5216) for further information.

TEC Service Software



The included TEC Service Software is a powerful tool that allows monitoring, data logging and full configuration of the TEC-1091 via a standard USB or an RS485 / RS232 TTL connection from a PC running Windows.


This tool is ideal for laboratory setups, product evaluation and commissioning. In conjunction with the comprehensive set of error codes and built-in descriptions, it facilitates diagnosis and debugging.

The software also supplies a user-friendly interface for maintenance (e.g. firmware upgrades), device calibration and basic data logging.


Please refer to the user manual for more information on features and system requirements.

Document Number: 5175S (30 October 2023)

Temperature Control (Autotuned PID)







TEC-1091 Ordering Information, Hardware Configuration

Example Configuration: TEC-1091-PT100-SCREW

TEC Model: - TEC-1091

Object Sensor Type:

- PT100 (4 Wire)
- PT1000 (4 Wire)
- NTC (2 Wire)
- VIN1 or VIN2

Terminal Configuration:

- SCREW (2.54mm Screw Terminal)
- PIN (2.54mm Pin Header)
- NC (no connector)
- (Special connector on request)

Object Sensor Type:

NTC: By default we mount an NTC1M. If you require an older version (NTC56K), please write it in the comment section of your order or contact us: contact@meerstetter.ch

Thermocouple: To use our TEC Controller with thermocouples type K, you need a TCI-1181 in addition to the TEC Controller with a VIN1 Object Sensor Type configuration.

Display Unit:

It is possible to connect a small or big OLED 2x16 / OLED 4x20 character display directly to the X4 connector. Please visit the DPY-1113 product web page for further information.

Customization:

Many hardware and software features of the TEC-1091 are customizable upon request. Please contact Meerstetter Engineering with your enquiry.

Meerstetter Engineering GmbH Schulhausgasse 12 3113 Rubigen, Switzerland



Phone: +41 31 529 21 00 Email: contact@meerstetter.ch Website: www.meerstetter.ch

Document Number: 5175S (30 October 2023)

Meerstetter Engineering GmbH (ME) reserves the right to make changes without further notice to the product described herein. Information furnished by ME is believed to be accurate and reliable. However typical parameters can vary depending on the application and actual performance may vary over time. All operating parameters must be validated by the customer under actual application conditions.