

TEC Controller / Peltier Driver ±4 A / up to ±21 V

## **Miniature OEM TEC Controller**



The TEC-1091 is a specialized TEC controller / power supply able to precision-drive a single Peltier element.

It features a true bipolar DC current source for cooling / heating, two temperature monitoring inputs (1x main, 1x auxiliary) and intelligent PID control with auto tuning. The TEC-1091 is fully digitally controlled, its hard- and firmware offer numerous communication and safety options.

The included PC-Software allows configuration, control, monitoring and live diagnosis of the TEC controller via USB, RS485 and RS232. All parameters are saved to non-volatile memory. Saving can be disabled for bus operation.

For the most straightforward applications, only a power supply, Peltier elements and two temperature sensors need to be connected to the TEC-1091. After power-up the unit will operate according to pre-configured values. (In stand-alone mode no control interface is needed.)

The TEC-1091 can handle either Pt100, Pt1000 or NTC temperature probes. For highest precision and stability applications a Pt100 / 4-wire input configuration is recommended. Analog measurement circuit is factory calibrated.

Auxiliary temperature input allow the connection of an NTC probe that is located on the heat sink of the Peltier element. This additional data is used to compensate for parasitic thermal conduction of Peltier element. Also, it allows the control of an external heat sink cooling fan.

The heating and cooling power is optimized by proprietary thermal management routines based on power balance models (for Peltier elements and resistive heaters).

Further functionality includes: Smooth temperature ramping, thermal stability indication and auto gain (NTC probes). The PC-Software allows data logging and configuration import/export.

Many features (hardware, software) of this OEM product are customizable upon request.

#### **Features**

#### **Output Stage:**

- DC Input Voltage: 5 24 V
- Output Voltage: 0 to ±21 V (max. ~ 0.9 · U<sub>IN</sub>)
- Output Current: 0 to ±4 A, <1% Ripple (TEC Modules with higher Output Power available)

#### Main Features:

- Temperature Sensor Types: Pt100, Pt1000, NTC
- Temperature Precision / Stability: <0.01°C
- Performance-optimized PID for Thermal Power Control
- Configuration / Diagn. over USB / RS485 PC Software
- Dimensions (L x W x H): 65 mm x 38 mm x 14 mm
- Efficiency: > 95% (@ 90% Load)
- Cooling not required (natural convection)
- Auxiliary Peltier Heat Sink NTC Temp. Sensor Input

# **Operation Modes:**

- Stand-Alone with out Live Control Interface
- Remotely-Controlled over USB, RS485 / RS422, RS232 TTL, I/O
- Script-Controlled over Lookup Table Read-Out

#### **Driver Modes:**

- DC Power Supply: Set Current or Voltage
- Temperature Control: PID Settings, Auto Tuning, optional Cool/Heat-Only or Resistor modes

### **Data Interfaces:**

- USB 2.0 1kV isolated (FTDI Chip)
- 1x RS485 / RS422
- 1x RS232 TTL

#### **General Purpose I/O Features:**

- 4x Digital I/O Signals (3.3 V / 5 V)
- Configurable as Input to control TEC-1091 (Enable, Temperature Up / Down etc.)
- Configurable as output to monitor TEC-1091 (Error Indication, Temperature Stable Indication etc.)

# **Optional Components:**

• Display Unit: 2x16 Char OLED (DPY-1113)

## **Further Information:**

- Please contact us for additional information, or consult the current TEC Controller User Manual (Document 5134).
- The TEC-1091 is part of the TEC-Family of Meerstetter TEC controllers. It is designed to operate alongside devices of the LDD-Family of laser diode drivers. Both families of drivers share the same system bus, design, technology and physical dimensions.



Absolute Maximum Ratings					
Supply voltage (DC) 27 V					
Supply current (DC)	4 A (On Board Fuse)				
Bipolar output voltage	±24 V				
Bipolar output current	±6 A				

Operating Ratings	
Ambient Operation	0 – 40°C *
Storage	-30 – 70°C
Humidity	5 – 95%, non-condensing

<sup>\*</sup> Only relevant for high power operation

# **Electrical Characteristics**

Unless otherwise noted:  $T_A$  = 25°C,  $U_{IN}$  = 24 V,  $R_{load}$  = 3.75  $\Omega$ 

Symbol	Parameter	Test Conditions	Min	Тур	Max	Units	
DC Power Supply Input:							
U <sub>IN</sub>	Supply voltage		4.9		24	V	
U <sub>IN</sub> Ripple	Ripple tolerance	UIN never below UIN min			300	$mV_{PP}$	
Output:							
louт	Bipolar current swing				±4	Α	
U <sub>оит</sub>	Bipolar voltage swing	U <sub>IN</sub> at least ~0.9 ⋅ U <sub>OUT</sub> / see diagram			±21	V	
Uout Ripple	Voltage ripple	@ 4 A		80		$mV_{PP}$	
System Cha	racteristics:						
η50%	Power efficiency	@ 50% load		96		%	
η90%	Power efficiency	@ 90% load		96		%	
Output Mon	itoring (IOUT Resolution	is 1.46mA; U <sub>OUT</sub> Resolution is 6.1mV)					
louт Read	Precision	@ 4.0 A		1	5	%	
Uout Read	Precision	@ 15.0 V		1	3	%	

**Safety Characteristics** Unless otherwise noted: T<sub>A</sub> = 25°C, U<sub>IN</sub> = 24 V

Symbol	Parameter	Test Conditions / Hints	Min	Тур	Max	Units
Input Trans	sient Overvoltage Prot	ection:				
U <sub>IN</sub> Trans.	Transients				27	V
Output Sta	ge Protection Delays:					
toff Short c	ircuit	Full load condition		10	30	μS
toff Power system limits		Current and voltage limits			200	μS
toff System failure		System status or temperature faults		100		ms
t <sub>IMMUN</sub> Immunity to transient noise		Duration of noise on temperature monitors	300			ms
	ge Current Supervision of OUT-currents differ too m					
I <sub>OUT_DIFF</sub>	Error threshold			800		mA

# Object Temperature Measuring Characteristics (Pt100 and Pt1000 Probes) $T_A = 25^{\circ}\text{C}$ , measurement configuration = 23bit / 4-wire / unshielded cable <50mm

Symbol	Parameter	Test Conditions / Hints	Min	Тур	Max	Units
T <sub>OBJ</sub> , RANGE	Range	Range is extendable upon Request	-50		+200	°C
Tobj, prec	Precision	Device temperature = 25°C (EN 60571 / IEC 751)		0.005	0.01	°C
T <sub>OBJ</sub> , COEFF	Temp. Coefficient	Relative to device temperature			1.6m	°C/K
T <sub>OBJ</sub> , NOISE	Value Noise	Reference measurement fluctuations while output stage operating @70% load		0.003		°C
T <sub>OBJ, REP</sub>	Repeatability	Repeated measurements of reference resistors after up to 3 days		0.005		°C



Object Temperature Measuring Characteristics (NTC Probes)

NTC thermistor resistive input characteristics translate into temperature ranges valid for only one type of NTC probe. Below example is given in the case of an NTC  $B_{25/100}$  3988K  $R_{25}$  10k temperature sensor.

Symbol	Parameter	Test Conditions / Hints	Min	Тур	Max	Units
Robj, range	Calibrated range	Standard Configuration $R_s = 56k\Omega$	3338	10.01	55742	Ω
TODO, TOTAL	(PGA = 1)	Corresponding temperature range	52.0 to -10.1		°C	
D	Extended range	Standard Configuration $R_s = 56k\Omega$	105		55742	Ω
Robj, range	(PGA = 1  or  8  or  32)	Corresponding temperature range	1	76 to -10.	1	°C

# **Sink Temperature Measuring Characteristics (NTC only)**

T<sub>A</sub> = 25°C, measurement configuration = 12bit / 2-wire / unshielded cable <50mm, °T probe = NTC B<sub>25/100</sub> 3988K R<sub>25</sub> 10k

Symbol	Parameter	Test Conditions / Hints	Min	Тур	Max	Units
Б	D		180		44600	Ω
KSINK, RANGE	Range	Corresponding temperature range		150 to -6.0	)	°C


# RS232 and General Purpose Digital I/O Characteristics (RES1 ... RES4, RX, TX)

Unless otherwise noted: T<sub>A</sub> = 25°C, U<sub>IN</sub> = 24 V


Symbol	Parameter	Comments	Min	Тур	Max	Units				
Input Chara	Input Characteristics:									
U <sub>IH</sub>	Logic high input threshold		2.31			V				
U <sub>IL</sub>	Logic low input threshold				0.99	V				
U <sub>IMAX</sub>	Maximum input voltage		-0.5		5.5	V				
(Microprocesse	,									
U <sub>OH</sub>	Logic high output voltage	Output current 8mA	2.9	3.3		V				
U <sub>OL</sub>	Logic low output voltage	Input current 8mA		0	0.4	V				
	ESD Protection: (Between Processor and Connector)									
U <sub>PP</sub>	ESD discharge	IEC61000-4-2			100	kV				
R <sub>A</sub>	Series resistance		170	200	230	Ω				



# **Package Outline and Pin Configuration**



- X1 and X2 can be equipped with different connector options.
   Please contact meerstetter engineering with your inquiry.
- For direct PCB mounting: If the TEC-Controller is powered by a sensitive power supply net, it is recommended decouple the TEC-Controller Supply by some filter components. Please contact us for further information.
- For direct PCB mounting: Do not place any component under the TEC-Controller.



Peltier element, temperature probes, power supply and connectors not included.




# **Operation-Modes and Communication Options**

The TEC-1091 is an OEM precision TEC controller that is primarily designed to operate as a stand-alone device. Once configured and in operation, its basic status is visually indicated by on-board green and red LEDs and their blinking pattern. More detailed status information can be polled at any time by industry-standard RS485 / RS232 connection or by USB (see box below). The TEC-1091 can also operate in a remotely-controlled manner, with parameters adjusted on the fly. The latest firmware upgrade introduced scripting capability by sequential lookup table read-out.

Configured as a DC power-supply, the TEC-1091 can handle current and voltage settings. In the remote-control case, temperature data may be passed on to be processed by the host.

Configurable parameters further include: sensor linearization (Pt100 / Pt1000) and Steinhart-Hart modeling (NTC), temperature acquisition hardware calibration, Peltier element modeling, PID controller auto tuning, nominal temperature ramping, current, voltage and temperature limits, error thresholds, etc. Please refer to the TEC Controller User Manual (Document 5134) for further information.

#### TEC Service Software




The included TEC Service Software is a powerful tool that allows monitoring, data logging and full configuration of the TEC-1091 via a standard USB or an RS485 / RS232 connection from a PC running Windows.

This tool is ideal for laboratory setups, product evaluation and commissioning. In conjunction with the comprehensive set of error codes and built-in descriptions, it facilitates diagnosis and debugging.


The software also supplies a user-friendly interface for maintenance (e.g. firmware upgrades), device calibration and basic data logging.


Please refer to the user manual for more information on features and system requirements.

# Temperature Control (Autotuned PID)









Meerstetter Engineering GmbH Schulhausgasse 12 3113 Rubigen, Switzerland



Phone: +41 31 712 01 01 Email: contact@meerstetter.ch Website: www.meerstetter.ch

Meerstetter Engineering GmbH (ME) reserves the right to make changes without further notice to the product described herein. Information furnished by ME is believed to be accurate and reliable. However typical parameters can vary depending on the application and actual performance may vary over time. All operating parameters must be validated by the customer under actual application conditions.